

# Web Browser Login



inet.anjels.com

**Anjels iNet Serial Number**

Submit

Step 1: Go to inet.anjels.com

1. Key in iNet S/N (Unique number)
2. Click Submit

MI 1:32 pm 2%

**Anjels iNet access**

Enter iNet from Remote  
远程网络登入iNet  
<http://27.104.96.8:8181>

Enter iNet at Local  
局域网登入iNet  
<http://192.168.1.81:8181>

Version 版本

Last known sync.  
2015-11-30 13:11:07

Please bookmark this page.

Step 2: Select access accordingly

For remote access login  
(overseas/outside)

For login when user connected to  
home WiFi network


# Login (Password)




## Step 3: Password Screen

1. Customers will be asked to key in the password during login for an extra layer of security
2. Password can also be changed on this screen

[Change Password 更换密码](#)



# iNet Homepage



# Sensor Status




..... M1 1:33 pm 2%

→ **Sensor Group** **Anjels**

	Door Sensor	Closed	<input checked="" type="checkbox"/> Enabled <input type="checkbox"/> Disabled	
	Living Sensor	Unoccupied	<input checked="" type="checkbox"/> Enabled <input type="checkbox"/> Disabled	
	Bedroom Sensor	Unoccupied	<input checked="" type="checkbox"/> Enabled <input type="checkbox"/> Disabled	
	Kitchen Sensor	Unoccupied	<input checked="" type="checkbox"/> Enabled <input type="checkbox"/> Disabled	
	Toilet Sensor	Unoccupied	<input checked="" type="checkbox"/> Enabled <input type="checkbox"/> Disabled	

ALL ON  Refresh  ALL OFF

# Live Monitoring Interface



# 24/7 Activity Trend Report

